



ZELFLERENDE HANDZENDER "Qzero"
CONTROL SELF-LEARNING "Qzero"

Qzero



**CORRECTE POSITIE
OM TE KOPIËREN**



INSTRUCTIES

NL

Procedure voor het kopiëren:

1. Druk op knop 1 van de "Qzero" en houd deze ingedrukt en druk gelijktijdig 4 maal op knop 2.
2. Laat beide knoppen los waardoor de LED iedere 2 seconden snel zal knipperen
3. Plaats de originele handzender aan de linker zijde tegen de "Qzero" (zie afbeelding hier boven)
4. Druk op de knop van de originele handzender die U wilt kopiëren en houd deze vast totdat de LED op de "Qzero" sneller gaat knipperen. Dit betekend dat de code is aangeleerd. Dit kan enkele seconden duren.
5. Terwijl de LED knippert, druk op de knop van de "Qzero" waar u de nieuw aangeleerde code wilt opslaan, totdat de LED uit gaat.
6. Reguleer de intensiteit van het signaal met het juiste apparaat (Sice Intensity Shooter code 6900273 of Sniffer code 4790783) op de compensator binnen in de handzender.*

*Voor deze procedure is een ceramische schroevendraaier noodzakelijk.

NOTITIE:

- Is de procedure niet succesvol of ontstaat er een fout, wacht dan even om vervolgens overnieuw te beginnen met de procedure bij punt 1.
- Het geheugen van de "Qzero" is volledig overschrijfbaar.
- Om de andere kanalen van de "Qzero" te programmeren, herhaal de procedure vanaf het begin (punt 1).

Batterij vervangen.

Lift het plastic front van de "Qzero" met een schroevendraaier.

De afstandsbediening "Qzero" is voorzien van een type 23A (12V) Alkaline batterij.

- Houdt rekening met de polariteit bij het vervangen van de batterij.
- Houdt de batterij weg van kinderen.
- Werp oude batterijen niet weg maar lever deze in bij de erkende batterij inzamel punten.

OPERATION MANUAL

UK

Procedure to copy:

- 1) Press and retain pressed the "Qzero" 1st button and at the same time press 4 times the 2nd button.
- 2) Release both buttons. So the "Qzero" LED will emit a quick flash every 2 sec.
- 3) Place the original remote control to clone perpendicular to the "Qzero" on its left side (see picture).
- 4) Press and retain the button to copy of the original remote control and wait till the LED of the "Qzero" changes the way to flash (faster), it means that the code has been learnt. This may take a few seconds.
- 5) While the LED flashes, press the "Qzero" button where you want to store the code just copied, until the LED switches off.
- 6) Adjust the intensity of the signal using the proper tool (Sice Intensity shooter code 6900273 or Sniffer code 4790783) on the compensator inside the remote control.*

* For this procedure a ceramic screwdriver is necessary.

NOTE:

- If the procedure is not successful or some errors occur, please wait some second and start the procedure again from point 1.
- "Qzero" memory is completely rewritable.
- To program the others channels of "Qzero", repeat the same procedure from the beginning (point 1).

Battery replacement

Lift the frontal plastic through the "Qzero" remote control split, using a screwdriver to lever.

The Remote control "Qzero" is powered by a 12v 23A Alkaline battery.

- When replacing the battery, check the right polarity - Keep the batteries out of the reach of children.
- Do not dispose into the environment the used batteries: take damage batteries in the waste disposal centers.